Dimension Guide

Washer Dryer



*Add 20mm for the hose protrusion at the back.

Please note! Dimensions to be used as a guide only. All customers MUST refer to the user manual supplied with the product for detailed installation instructions. © 2021 Electrolux S.E.A PTE. LTD. E_DIM_EWW1042AEWA_Aug20

