Dimension Guide

Top freezer refrigerator

Н

Model:

н

 W1

90°

ETB2502J-H



When positioned in a corner area, spacing of at least 350mm on the hinge side will allow the doors to open enough to enable the removal of bins and shelves.

Top Mount	Door width	Total depth	Maximum	Cabinet	Cabinet	Depth door	Cabinet
Models	(W)	(D)	height (H)	width (W1)	depth (D1)	open (D2)	height (H1)
ETB2502J-H	543	626	1470	540	551	1110	1455

Front face of bench aligned to front

corner edge of cabinet.

350 mm

Important! Please ensure that the access to your kitchen (including doorways, corridors, island benches, etc) allows sufficient clearance to move your fridge into position. Please note! Dimensions to be used as a guide only. All customers MUST refer to the user manual supplied with the product for detailed installation instructions. © 2021 Electrolux S.E.A PTE. LTD. E_DIM_ETB2502J-H_Dec20

