
Dimension Guide

Top freezer refrigerator

Model:

ETB3460K-H



If you do not have a cupboard with allowance for air flow above the refrigerator, the recommended clearance

Please note: Doors are designed to sit proud of cabinetry (not flush).

When positioned in a corner area, spacing of at least 350mm on the hinge side will allow the doors to open enough to enable the removal of bins and shelves.

| Top Mount | Door width | Total depth | Maximum | Cabinet | Cabinet | Depth door | Cabinet |
|------------|------------|-------------|------------|------------|------------|------------|-------------|
| Models | (W) | (D) | height (H) | width (W1) | depth (D1) | open (D2) | height (H1) |
| ETB3460K-H | 598 | 650 | 1646 | 595 | 586 | 1200 | 1630 |

Important! Please ensure that the access to your kitchen (including doorways, corridors, island benches, etc) allows sufficient clearance to move your fridge into position. Please note! Dimensions to be used as a guide only. All customers MUST refer to the user manual supplied with the product for detailed installation instructions. © 2021 Electrolux S.E.A PTE. LTD. E_DIM_ETB3460K-H_Oct20

