
Dimension Guide

Top freezer refrigerator

Model:

ETB3740K-A



If you do not have a cupboard with allowance for air flow above the refrigerator, the recommended clearance

area on top increases to 90mm.

Please note: Doors are designed to sit proud of cabinetry (not flush).

When positioned in a corner area, spacing of at least 350mm on the hinge side will allow the doors to open enough to enable the removal of bins and shelves.

Top Mount	Door width	Total depth	Maximum	Cabinet	Cabinet	Depth door	Cabinet
Models	(W)	(D)	height (H)	width (W1)	depth (D1)	open (D2)	height (H1)
ETB3740K-A	598	650	1756	595	586	1200	

Important! Please ensure that the access to your kitchen (including doorways, corridors, island benches, etc) allows sufficient clearance to move your fridge into position.

Please note! Dimensions to be used as a guide only. All customers MUST refer to the user manual supplied with the product for detailed installation instructions.

© 2021 Electrolux S.E.A PTE. LTD. E_DIM_ETB3740K-A_Oct20

